

Pos.	Référence	Désignation	
005	5024741000/9	GRILL	
006	5023267200/1	RESSORT	
007	5024658400/2	ARRET,FILTRE	
009	5026233100/7	FILTRE	
9A	5026233600/6	FILTRE À GRAISSE	
9B	5024740800/3	FILTRE GRAISSE	
023	5024014000/9	SUPPORT, DOUILLE LAMPE	
024	5024014100/7	SUPPORT, INFERIEUR	
025	5023263600/6	FERMETURE, DOUILLE LAMPE	
026	5023265200/3	LAMPE	
028	5021477700/0	DOUILLE	
029	5026740200/1	DIFFUSEUR DE LUMIÈRE	
032	5026233000/9	Filtre à graisse	
37	5026570600/7	BOUTON	
37	5024663900/4	BOUTON	
043	5026232800/3	MOTEUR GÉNÉRAL	
049	5024008900/8	COURONNE MOBILE	
050	5024008600/4	Support moteur	
052	5024008800/0	SERRE-CABLE, SUPPORT MOTEUR	
057	5016607900/9	REGISTRE	
084	5026233500/8	CHARIOT	
086	5024011500/1	FLASQUE	
092	5024665600/8	SUPPORT, TABLEAU DE BORD	
095	5026233400/1	BANDE,PANNEAU	
099	5024741200/5	AR FILTRE	
110	5024665800/4	Joint	
112	5024008700/2	PROTECTION	
114	5024660800/9		
117	5026249500/0	HABILLAGE	
118	5024741400/1	CHEMINEE	
119	5024741500/8	CHEMINEE SUPERIEURE	
120	5024741600/6	SUPPORT, SUPERIEUR, CHEMIN!E	
121	5024741700/4	RACCORD, FIXATION, CHEMIN!E	
135	5026233200/5	PLAQUE DÉCOR	
145	5024661000/5	Boitier,alimentation	
147	5025103900/9		
147	5025104000/7	CEDDE CADI E DOITE	
152	5024009600/3	SERRE-CABLE,BOITE	
223	5024666000/0	LEVIER COMMANDES	
228	5024666100/8	PLATINE COMMANDES	
229	5023395900/1	LAMPE TEMOIN	
230	5024666200/6	COUVERCLE, TABLEAU DE BORD	
234	5024666300/4	BOITE, TABLEAU DE BORD	
266	5024009000/6	PROTECTION, EXTERIEURE	
274	5024658900/1	Boilier connexion	
332	5024661800/8	BOUCHON	
376	5024741800/2	PLAQUE SOUPAPE	
472	5026232900/1	ÉTRIER	
999	5026249600/8	NOTICE UTILISATION	
999	5027276300/9	ENSEMBLE ACCESSOIRES, FIXATION,	

FILTRE, CHARBON, 10PIECES

999

5024984200/1