



A100




A190



A180

A180


A111




A113

A114


A115




A120



A200




A150




A130

A110



Transparent door

Opaque round door



Note

Do not use the door glass if it is cracked or broken. The door glass is not covered by the warranty. If you have any questions, please contact the service center.

Note

If you want to exchange the door glass, please contact the service center to replace the door glass.

