




89B

89A




2

(OPTIONAL)

735

738



737

SOGEDIS
ELECTROMENAGER






641




16B



16






SOGEDIS
ELECTROMENAGER


654B



434



571




572


431/413



401



533



449



70



499

ELECTRONIC
CONTROL

200



696



154

189



695



460
(Gasket)

155

(OPTIONAL)
DOOR HANDLE

630



135



164



174B



174



187



701




700



463



238A



203



201

70

205

205



INVERTER
(OPTIONAL)

