



OR	DN	TS	TS	TURBIDITY SENSOR
	TRC	RI	RI	RINSEAD INDICATOR
	OR	SI	SI	SALT INDICATOR
WH	DN	FM	FM	FLOWMETER
	TRC	NTC	NTC	NTC SENSOR
	OR	DV	DV	DIVERTER
BL	DN	IV	IV	INLET VALVE
	TRC	FS	FS	FLOAT SENSOR
	OR	DP	DP	DRAIN PUMP
RE	DN	TF	TF	TURBO FAN
	TRC	PS	PS	PRESSURE SWITCH
	OR	DS	DS	DOOR SWITCH
BR	DN	DE	DE	AC DISPENSER
	TRC	HE	HE	HEATING ELEMENT
	OR	CP	CP	CIRCULATION PUMP
PI	DN	C	C	CAPASITOR
	TRC	RV	RV	REGENERATION VALVE
	OR	SF	SF	HEATING SAFETY
VI	DN	RW	RW	ROTARY SWITCH
	TRC	BLDC	BLDC	BLDC PUMP
	OR	PST	PST	POWER SUPPLY TERMINAL
BL	DN	MS	MS	MAIN SWITCH
	TRC	DUB	DUB	DISPLAY AND USER BOARD
	OR	LUX	LUX	DISPLAY END USER BOARD
GR	DN	LUX	LUX	DISPLAY END USER BOARD
	TRC	LUX	LUX	DISPLAY END USER BOARD
	OR	SFL	SFL	SAFETY LOCK
VL	DN	LM	LM	LIGHT MODUL
	TRC	DCD	DCD	DC DISPENSER
	OR	ALM	ALM	AMBIENT LIGHT MODUL
YE	DN	PSW	PSW	PRESSURE LEVEL SWITCH
	TRC	WHS	WHS	WATER HARDNESS SENSOR
	OR	CULCD	CULCD	CONTROL UNIT LCD
GR	DN	ATSW	ATSW	AUTOMATIC ON OFF SWITCH
	TRC	LCD	LCD	LIQUID CRYSTAL DISPLAY
	OR	PFLT	PFLT	PARASIT FILTER
GR	DN	TRF	TRF	TRANSFORMERS LIGHT MODUL
	TRC	ALL	ALL	AMBI LIGHT LED
	OR	ACD	ACD	AUTOMATIC OPEN DOOR
GR	DN	TFT	TFT	TFT LCD
	TRC	FC	FC	FERRIT CORE
	OR	WRV	WRV	WATER RECYCLING VALF
GR	DN	WRP	WRP	WATER RECYCLING PUMP
	TRC	SC	SC	SILICON CABLE
	OR	HIP	HIP	HEATER INTEGRATED PUMP

