

CR	FRONTAL CHANGE	TS	TURBIDITY SENSOR
CR	FRONTAL CHANGE	RI	RINSEAD INDICATOR
CR	FRONTAL CHANGE	SI	SALT INDICATOR
CR	FRONTAL CHANGE	FM	FLOWMETER
WR	WHITE	NTC	NTC SENSOR
WR	WHITE	DV	DIVERSTER
BLU	BLUE	IV	INLET VALVE
BLU	BLUE	FS	FLOAT SENSOR
BLU	BLUE	DP	DRAIN PUMP
RED	RED	TF	TURBO FAN
RED	RED	PS	PRESSURE SWITCH
RED	RED	DS	DOOR SWITCH
BR	BROWN	DE	AC DISPANSER
BR	BROWN	HE	HEATING ELEMENT
BR	BROWN	CP	CIRCULATION PUMP
BR	BROWN	C	CAPASITOR
GRN	GREEN	RV	REGENERATION VALVE
GRN	GREEN	SF	HEATING SAFETY
GRN	GREEN	RV	ROTARY SWITCH
VI	VIOLET	BLDC	BLDC PUMP
VI	VIOLET	PST	POWER SUPPLY TERMINAL
MS	MAIN SWITCH		
DUB	DISPLAY AND USER BOARD		
U1X	DISPLAY END USER BOARD		
U2X	DISPLAY END USER BOARD		
U3X	DISPLAY END USER BOARD		
SFL	SAFETY LOCK		
LM	LIGHT MODUL		
DCD	DC DISPANSER		
ALM	AMBIENT LIGHT MODUL		
PSW	PRESSURE LEVEL SWITCH		
WH	WATER HARDNESS SENSOR		
CULCD	CONTROL UNIT LCD		
ATSW	AUTOMATIC ON OFF SWITCH		
LCD	LIQUID CRYSTAL DISPLAY		
PFLT	PARASIT FILTER		
TRF	TRANSFORMERS LIGHT MODUL		
ALL	AMBI LIGHT LED		
AOD	AUTOMATICAL OPEN DOOR		
TFT	TFT LCD		
FC	FERRITY CORE		
WRV	WATER RECYCLING VALF		
WRP	WATER RECYCLING PUMP		
SC	SLICCON CABLE		
HIP	HEATER INTEGRATED PUMP		

