



DR	ON PORT/NOV	TS	TURBIDITY SENSOR
DR	ON PORT/NOV	RI	RINSE/END INDICATOR
DR	ON PORT/NOV	SI	SALT INDICATOR
VH	ON PORT/NOV	FM	FLOWMETER
VH	ON PORT/NOV	NTC	NTC SENSOR
VH	ON PORT/NOV	DV	DIVERTER
BLU	ON PORT/NOV	IV	INLET VALVE
BLU	ON PORT/NOV	F/S	FLOAT SENSOR
BLU	ON PORT/NOV	DP	DRAIN PUMP
RE	ON PORT/NOV	TF	TURBO FAN
RE	ON PORT/NOV	PS	PRESSURE SWITCH
RE	ON PORT/NOV	DS	DOOR SWITCH
BR	ON PORT/NOV	DE	AC DISPENSER
BR	ON PORT/NOV	HE	HEATING ELEMENT
BR	ON PORT/NOV	CP	CIRCULATION PUMP
PI	ON PORT/NOV	C	CAPASITOR
PI	ON PORT/NOV	RV	REGENERATION VALVE
PI	ON PORT/NOV	SF	HEATING SAFETY
VI	ON PORT/NOV	RW	ROTARY SWITCH
VI	ON PORT/NOV	BLDC	BLDC PUMP
BL	ON PORT/NOV	PS/T	POWER SUPPLY TERMINAL
BL	ON PORT/NOV	MS	MAIN SWITCH
BL	ON PORT/NOV	DU/B	DISPLAY AND USER BOARD
GR	ON PORT/NOV	UI/X	DISPLAY END USER BOARD
GR	ON PORT/NOV	UI/2X	DISPLAY END USER BOARD
GR	ON PORT/NOV	UI/3X	DISPLAY END USER BOARD
YL	ON PORT/NOV	SFL	SAFETY LOCK
YL	ON PORT/NOV	LM	LIGHT MODUL
YL	ON PORT/NOV	DCD	DC DISPENSER
YL	ON PORT/NOV	ALM	AMBIENT LIGHT MODUL
YE	ON PORT/NOV	PSW	PRESSURE LEVEL SWITCH
YE	ON PORT/NOV	VHS	WATER HARDNESS SENSOR
ERY	ON PORT/NOV	CU/LCD	CONTROL UNIT LCD
ERY	ON PORT/NOV	ATSW	AUTOMATIC ON OFF SWITCH
ERY	ON PORT/NOV	LCD	LIGUID CRYSTAL DISPLAY
ERY	ON PORT/NOV	PFLT	PARASIT FILTER
ERY	ON PORT/NOV	TRF	TRANSFORMERS LIGHT MODUL
ERY	ON PORT/NOV	ALL	AMBI LIGHT LED
ERY	ON PORT/NOV	ADD	AUTOMATIC OPEN DOOR
ERY	ON PORT/NOV	TFT	TFT LCD
ERY	ON PORT/NOV	FC	FERRIT CORE
ERY	ON PORT/NOV	WRV	WATER RECYCLING VALF
ERY	ON PORT/NOV	WRP	WATER RECYCLING PUMP
ERY	ON PORT/NOV	SC	SILICON CABLE
ERY	ON PORT/NOV	HIP	HEATER INTEGRATED PUMP
ERY	ON PORT/NOV	0.25	0.25 mm CABLE
ERY	ON PORT/NOV	0.35	0.35 mm CABLE
ERY	ON PORT/NOV	0.38	0.38 mm CABLE
ERY	ON PORT/NOV	0.50	0.50 mm CABLE
ERY	ON PORT/NOV	0.75	0.75 mm CABLE
ERY	ON PORT/NOV	1.00	1.00 mm CABLE
ERY	ON PORT/NOV	1.50	1.50 mm CABLE
ERY	ON PORT/NOV	1.50	1.50 mm SILICON CABLE