


Oven switch diagram



ELECTRIC DIAGRAM KEY

- F1 Oven switch
- TE Oven thermostat
- LF Oven lamp
- S1 Thermostat pilot lamp
- TL Thermal overload
- M Terminal block
- C Top element
- G Grill element
- S Bottom element
- V Fan
- T Earth connection

1			
N°	MODIFICHE	DATA	FIRMA

